





DISPLAY ASSEMBLY









1. Unfold display.

2. Fold easel wings towards one another.

3. Fold down easel flaps and lock them into position.

4. Assembly complete!